

13.3.8 CHANGING PIN CODE BY USING MASTER PROGRAMMING KEY

If you have entered the PIN code of the programming key incorrectly more than five times, use the Change PIN Code function with the help of the master programming key. Open **CLIQ Tasks / Functions / Change PIN using Master programming key**. Place the master programming key in port 1. Place a programming key in port 2.

- 1 Enter the PIN code of the master programming key.
- 2 Enter the new PIN code of the programming key.
- 3 Confirm the new PIN code.
- 4 Place a programming key in port 1.
- 5 The PIN code of the programming key has now been changed.

