

# **ASSA ABLOY**

## **Pairing a CLIQ Connect key to a phone**

# Table of Contents

<b>1</b>	<b>INTRODUCTION .....</b>	<b>3</b>
<b>2</b>	<b>VERSIONS .....</b>	<b>3</b>
2.1	iOS .....	3
2.2	Android .....	3
<b>3</b>	<b>INSTRUCTIONS .....</b>	<b>3</b>
3.1	Pair a CLIQ Connect key to a phone.....	3
3.2	Unpair a CLIQ Connect key from a phone .....	3
3.3	Updating a CLIQ Connect key.....	3

# 1 Introduction

This document contains instructions on how to pair a CLIQ Connect key to the CLIQ Connect mobile phone app.

## 2 Versions

This release of CLIQ Connect is compatible with the following components:

### 2.1 iOS

iPhone or iPad with iOS version 8.0 or later

### 2.2 Android

Android, version 4.4 or later

## 3 Instructions

### 3.1 Pair a CLIQ Connect key to a phone

First, make sure that Bluetooth is enabled on the phone. The key will only be able to be paired with a phone for 2 minutes after the battery has been refitted. Hence, take out the battery for ~40 seconds and insert it again. The CLIQ Connect key will appear in CLIQ Connect mobile app. Click on the plus sign to pair the key with the phone.

When a CLIQ Connect key has been paired with a phone, it will not accept any other pairing requests from any other phones. If you want to pair the CLIQ Connect key with another phone you need to unpair it first. See below for more information.

### 3.2 Unpair a CLIQ Connect key from a phone

The key can be unpaired/removed from the phone via the CLIQ Connect mobile app.

To unpair a CLIQ Connect key when the phone is unavailable you can instead remove the battery from the key for ~40 seconds. Then insert the key again. The key can now be paired with another phone.

### 3.3 Updating a CLIQ Connect key

Once a CLIQ Connect key is paired to the phone it can be updated via the CLIQ Connect app.